

NEW VEHICLE BREAK-IN

All Corvette models have a recommended break-in period during the first 1,500 miles (2414 km).

PART/DRIVING BEHAVIOR	TIME PERIOD	RECOMMENDED ACTION
Tires	First 200 miles (322 km)	Drive at moderate speeds and avoid hard cornering
Brake linings	First 200 miles (322 km)	Avoid making hard stops (recommended every time brake linings are replaced)
Full-throttle starts and abrupt stops	First 500 miles (800 km)	Avoid full-throttle starts and abrupt stops
Exceeding 4000 rpm	First 500 miles (800 km)	Avoid exceeding 4000 rpm
Cruise control or driving at one constant speed	First 500 miles (800 km)	Avoid cruise control or driving at one constant speed
Track or competitive driving	First 1,500 miles (2414 km)	Do not participate in track events, sport driving schools or similar activities
Engine oil maintenance	First 1,500 miles (2414 km)	Check engine oil with every refueling and add if necessary (oil and fuel consumption may be higher than normal during the first 1,500 miles)