



2020 Chevrolet Corvette shown with optional equipment.

# CORVETTE REMOVABLE ROOF PANEL



## Removable roof panel lets you enjoy the outside air

On the 2020 Corvette Stingray Coupe, you can remove the roof panel by releasing latches in the cabin. You can then stow the roof panel in your rear trunk.

### WHAT YOU NEED TO KNOW

- There are three latches you must undo to remove the roof panel—one underneath each of the sun visors and one in the rear on the ceiling between the seats
- You must open your windows before removing the roof panel
- The first time you try to remove the roof panel, you may want to try doing it with a friend to avoid dropping the roof panel or scratching your vehicle

### DOES MY VEHICLE HAVE THIS FEATURE?

- This feature is currently only available on the 2020 Corvette Stingray Coupe

### HOW IT WORKS

#### Removing the Roof Panel

##### Here's how to remove your vehicle's roof panel:

- First, unlock your vehicle and open the windows
- Get into your vehicle and unlatch the three roof panel latches
  - There are two latches in the front underneath each of the sun visors. Pull the latch on the driver side to the left and the one on the passenger side to the right
  - There is also a latch behind the seats on the roof in the center of the cabin. Press up on the latch paddle while pressing the small release tab, then release the paddle to the open position
- Then, exit your vehicle, open the rear trunk and prepare to remove the roof panel
  - If this is your first time removing the roof panel, make sure there is nothing else in your trunk to make inserting the panel easy
- Push up on the underside of the roof panel near the front until it comes off the latches. Then, grab the front and rear ends of the panel and lift it up off the vehicle in a slight forward motion
  - If this is your first time doing this, it may be helpful to have a friend help you remove the roof panel. It weighs about 16 pounds
- Insert the panel into the trunk rear end down with the painted surface facing you. There are two “feet” for the roof panels that the bottom will click into
- There are also two clips toward the top of the trunk that the roof panel will attach to. Line up the bottom “feet” first before snapping in the top clips
  - You can use the lines on the roof panel to help guide it into the trunk. The lines on the panel should be just outside the top clips on the trunk
- Press the roof panel firmly into place and ensure it fits snugly and clicks into the top and bottom trunk clips before closing the rear trunk. Pull slightly along the top edge of the panel to then ensure it is locked into position

### COMFORT & CONVENIENCE

F1: March 2020

For GM dealership personnel use only. Not intended for advertising purposes. GM reserves the right to make changes at any time, without notice, in prices, colors, materials, equipment, features, specifications and availability. Product information is preliminary and reflects approved content at time of publishing.

# CORVETTE REMOVABLE ROOF PANEL

## CONTINUED



### Reattaching the Roof Panel

#### Here's how to reattach the roof panel:

- First, unlock your vehicle and open the windows
- Then, exit your vehicle, open the rear trunk and prepare to retrieve the roof panel
- To remove the roof panel from the trunk, pull firmly on the top of the panel toward you and it will unlatch. It takes some effort to do this
- Before retrieving the roof panel from the trunk, make sure the cabin roof panel latches are in the open position you set them to when you removed the roof panel
- Grip the top and bottom ends of the roof panel and lift it out of the trunk
- Line the studs on the rear end of the roof panel with the receiver slots on the vehicle's body. Guide the studs into the cups while gently lowering the front edge of the panel into the front latches. Then, lay the front of the roof panel onto the front roof panel latches
- Push down on the front of the panel to ensure it's snugly on the latches
- Enter your vehicle and close all three roof panel latches

### USAGE TIPS

- If you unlatch the roof panels while your vehicle is locked, the car alarm will sound
- There is some room for small items underneath the roof panel in the trunk when it is stowed
- Do not attempt to stow the roof panel in the front trunk
- Do not drop the roof panel or lay it on the ground—it may get damaged

### FAQs

#### Can I remove the Corvette roof panel by myself?

Yes. However, if it's your first time removing the panel, you may want someone else to help you to ensure the roof panel is not dropped.

#### Where are the latches I need to undo to remove the roof panel?

Two of the latches are underneath the sun visors in the front seats and the third is on the roof in the rear center of the vehicle between the seats.

### MORE INFORMATION

**Customers:** For more information on your vehicle, including vehicle features and maintenance, visit [GM Owner Center](#) →

**Dealers:** For information on other In-Vehicle Technology features, visit the [In-Vehicle Technology Library](#) →

### RELATED FEATURES

- Convertible Top Controls
- Dual Trunk Cargo